

## 10383uk How do I register RF Activote devices (866MHz / 915MHz) with ActivInspire?

### Applicable to:

ActivInspire

RF Activote devices (866MHz / 915MHz)


RF Hub

RF Enabled Activboard

### Solution:

1. Start ActivInspire.
2. Connect an ActivHub AH1 or your RF Enabled Activboard (50" / 60" / 78") to your computer.
3. Distribute the ActiVote devices.


To register:

1. Open the Voting Browser and click on **Device Registration**  The 'Device Registration' Dialog Box opens. It shows:
  - A picture of an ActivHub AH1 or Activboard.
  - ActiVote and ActivSlate devices under Device Groups.



2. Select ActiVotes and click on **Register**.
3. Enter the number of devices you want to register (or use the arrows) and click on **Next**.

The next window shows clear instructions, with photos, so your students can finish the registration (you might like to practise the procedure first!).



If the students are finishing the registration, they have to:

- a. Press and hold the central **Registration** button on the ActiVote devices. The top red light flashes, followed by the green light.
- b. Release the **Registration** button.

ActivInspire registers the devices to the ActivHub one by one. You can see the number updated in the window.

When this number is equal to the number you entered in Step 3. above, the window closes automatically, because all devices have been registered. If registration fails for any of the devices, the window must be closed manually.